



REAR BADGE PLACEMENT GUIDELINES - AUDI A3/S3/RS3

A3/SPORTBACK:

DIMENSION A - 55MM

DIMENSION B - 58MM

DIMENSION C - 43MM

- 1 - COVER EDGE IN
FENDER

SEDAN:

DIMENSION A - 75MM

DIMENSION B - 78MM

DIMENSION C - 33MM

- 1 - COVER EDGE IN
FENDER