



SIDE BADGE PLACEMENT GUIDELINES - AUDI B9 Q5/SQ5

1 - TYPE/EMBLEM

-S-LINE/V6T

DIMENSION A - 76MM

DIMENSION B - 74MM

DIMENSION C - 39.5MM

2 - REFERENCE EDGE IN
FENDER

3 - REFERENCE EDGE ON
FENDER